

Bodyguard II

Flächenbelastungstabelle / Table of area loading



Start Weight / Take of weight(kg)	50	55	60	65	70	75	80	85	90	95	100	105	110	115	120	125	130	135	140	145	150	
BodyGuard II XS	2,1	2,3	2,6	2,8	3,0	3,2	3,4															
BodyGuard II S				2,5	2,6	2,8	3,0	3,2	3,4	3,6												
BodyGuard II M							2,8	2,9	3,1	3,3	3,4	3,6	3,8									
BodyGuard II L										3,0	3,2	3,3	3,5	3,7	3,8	4,0	4,1					
BodyGuard II XL																3,4	3,6	3,7	3,9	4,0	4,1	4,3

